Plaster Adhesives, Fillers & Consolidants

Pre Wet

1. 3 IPA
2. 3 water
3. 3 MC76 (strong resin. Do not add MC76 directly into IPA- mix water and resin first)

Penetrating Adhesives

Viscous	Less Viscous	Even Less Viscous
1. 3 alcohol	1 alcohol	2 alcohol
2. 1 water	1 water	1 water
3. MC76	2 MC76	3 MC76

Adhesive

3 parts MC76
2 parts LC67

Thickener

500 ml water
100 ml ASE60 (Acrasol)
10 ml 27% ammonia (PH 8)

Filled Adhesive

2 IG101
2 lime
2 fluid coke
3 acrylic resin (3 MC76 / 2LC67)
thickener as required. less is better